CODEC



Used components: C500...531
D500...502
N500...501
R500...534

©Nokia Corporation

Connection



©Nokia Corporation

MCU and Memories



©Nokia Corporation

DTMF and FSK



used components: B600
C600...617
D600...606
L600
R600...618
V601

Power



USED COMPONENTS C800...820
J800...802
L800
N800
R800..807

©Nokia Corporation

RS232





©Nokia Corporation

Main Block



©Nokia Corporation

Trunk Interface



Used components: C300...335
J300
L300...311
N300
R300...330
V300...302
Z300

Extension Interface





used components: C400...443
D400...401
L400...402
R400...444
V400...410

©Nokia Corporation

Assembly Values Diagram Bottom



©Nokia Corporation

Assembly Values Diagram Top



©Nokia Corporation

©Nokia Corporation